Changing the Way Objects Look in Floor Plan View

Reference Number: **KB-00473** Last Modified: **July 15, 2021**

The information in this article applies to:



QUESTION

I would like to change the colors used in plan view for a variety of objects - for example, cabinets, doors, electrical items and dimension lines. How do I do this?



ANSWER

In Chief Architect, you can change both the line color and the line style used to represent nearly all objects in floor plan view - including walls, floors, furniture and many other objects. Line color and style can be changed for an entire category of objects, organized by layer in the program, or for individual objects.

To change the display of a layer

1. Select **Tools> Layer Settings> Display Options** 📝 from the menu.

2. In the Layer Display Options dialog:

ayer Sets				- C															
Default Set	t ·	Cop	by Set		Modif	iy All La	yer Set	s											
Properties for Selec	ted Laver Set																		
None City	Lieu Layer Set						1												
Name Filte	er:																		
Name	0		Used	Disp	Mat	Lock	Color	Weight	Line Style										
Fixtures, Exterior				\checkmark	M			18											
Fixtures, Interior				~	Μ		5	18											
Fixtures, Labels					Μ		1	10	3 										
Floor Surfaces Footings Footings, Deck Post Footings, Post Footings, Step Markers			+++++++++++++++++++++++++++++++++++++++	× ×	M M M			10 35 35 35 18											
										Foundation					M			35	
										Select All	New	New Co		Delete		1	Reset Names		
																		1	
										Properties for Selec	ted Layer - "F	ixtures,	Exterior	1					
	🗹 Display	Mat Mat	terials Li	st 🗌	Lock														
Color:																			
Line Weight	: 18]																
			1				-												
Line Style:							Lib	orary											

- Click on a layer to select it.
- In the **Properties for Selected Layer** section at the bottom of the dialog, select the desired **Color** and **Style** for the lines representing all objects on this layer.

- If you would like your changes to affect all layer sets, check the box beside **Modify All Layer Sets** at the top of the dialog.
- Click **OK** to close the dialog and apply your changes.

The Modify All Layer Sets options is a state, rather than an action, which means that it will remain checked until you uncheck it again, or until you close the Layer Display Options Dialog box.

To change the display of a single object

- 1. With the **Select Objects** tool active, click on an object that you would like to modify the 2D display of to select it.
- 2. Click the **Open Object** edit button to open the object's specification dialog.
- 3. On the LINE **S**TYLE panel of the specification dialog:

General	Line Options			
Style	Layer:	Default	Stairs & Ramps 🔻	Define
Breakline				
Railing	Color:	By Layer		
Newels/Balusters		_		
Rails	Style:	By Layer		Library
Line Style	Weight:	By Laver	25	
Fill Style	Weighte	E 0/ 20/C		
Materials	Bumping			
Arrow		CAD Stop	s Move	
		Wall Stops	s Move	
	Drawing Group	-		
		Default: 22	- Stairs/Ramp/Landing	

- Click the color bar and select the desired **Color** for your line in the Color Chooser dialog.
- Select a Line Style from the **Style** drop-down list.

- Select a Line Weight which will display when Show Line Weights ______ is turned on as well as when printed.
- Also, the drawing order of the object that's open can be changed if it becomes superimposed with other objects. This can be done using the **Drawing Group** drop down.
- Some objects, such as walls, doors, and windows do not have a LINE STYLE panel. Instead, you can place individual objects on any layer that you need to on the LAYER panel of the specification dialog.
- 5. A number of objects also have a FILL STYLE panel in both their defaults and specification dialogs.

Polyline Solid	Specification		×
General	Pattern		
Polyline Selected Line Line Style	Type:	Hexagon Library 	
Fill Style	Width:	2"	(\rightarrow)
Materials Label	Height:	2"	\succ
	Scale:	1.0	
	Offset and Angle		
	Horizontal Offset:	: 0"	
	Vertical Offset:	0"	\rightarrow
	Angle:	0.0°	(\rightarrow)
Арр	Appearance	12 AV AV	
	Line Weight:	1	
		Transparent Pattern Background	
	Color:		
		O Custom Color	
		Use Layer Color	
		O Use Background Color	
	Transparency:	0%	
		Add To Library	Preview Width: 12" -

- Select a Fill Pattern from the **Type** drop-down list.
- Specify the pattern's **Scale** options to your liking.

- Specify the **Offset** and **Angle** settings.
- Use the **Appearance** settings to choose a **Color** for the pattern lines and specify **Transparent Pattern Background** if desired.
- The **Transparency** of the pattern lines can also be adjusted.

Related Articles

Understanding Layer Sets (/support/article/KB-00765/understanding-layer-sets.html)



Privacy Policy (/company/privacy.html)