Message: Update View to Layout

Reference Number: **KB-02713** Last Modified: **July 15, 2024**

The information in this article applies to:



DESCRIPTION

Sometimes when I close a cross section view, a message will ask whether I want the view to be updated on the layout page:

"#272032489 - This view was previously sent to layout. Would you like the layout view to be updated to reflect your changes? Note that if you update the layout view, any work done to it using the Edit Layout tool will have to be redone."

Why is this occurring?

ANSWER

Cross Section/Elevation A, **Backclipped Cross Section A**, and **Wall Elevation I** views sent to layout as Plot Line views are semi-dynamic. This means that:

• CAD, text, and Dimensions that you draw in the view are immediately shown in the layout view.

• Any changes to the 3D model are not shown in the layout view until you tell the program to update the view.

When you close one of these Plot Line views, and the view in question has been previously sent to layout, this message box may display, allowing you to choose whether to update the layout view or not.

- If you would like the view on the layout page to be updated to show changes to the 3D model, click **Yes**. The advantage to choosing Yes is that the layout view will show the current state of the model.
- The disadvantage is that if you modified the layout view using the **Edit Layout** [1] tool, your changes will be lost. If you would like the view on the layout page to remain as it is, click **No**.
- The advantage of choosing No is that any work you may have done using the Edit
 Layout tool will be saved. The disadvantage is that the layout view may not show the 3D model in its current state.



Privacy Policy (/company/privacy.html)