Chief Architect[®] Architectural Home Design Software

Using CAD to Walls from an Imported DWG/DXF

Reference Number: **KB-00170** Last Modified: **February 11, 2024**

The information in this article applies to:



QUESTION

I have imported a <u>DWG</u> or <u>DXF</u> file and would like to convert the 2D lines to 3D objects such as walls, doors and windows. How can I accomplish this task using the <u>CAD</u> to Walls tool?

ANSWER

The CAD to Walls tool can be used to convert <u>CAD</u> lines in floor plan view into 3D architectural objects. Two or more parallel CAD lines can be converted to both straight or curved walls or railings. CAD lines representing windows and doors can also be converted.

To import a DWG/DXF file

1. Launch Chief Architect and start a **New Plan**

- 2. Select File> Import> Import Drawing (DWG, DXF) the menu.
- 3. In the **Import Drawing Assistant** dialog that displays, click **Next** or **Continue** to go to the **Select File** portion of the dialog:

in port of draining resistance	
Select File Select the file to import and specify how some CAD entities are handled.	
Click the Browse button to select a file to import.	
File: C:\Users\joshua\Documents\Woodstone.dwg	Browse
Convert lines with shared end points into:	
Polylines	
Boxes	
How would you like to handle CAD blocks that are not referenced in the drawing?	
O Import all CAD blocks	
Only import CAD blocks that are referenced in the drawing	
Hatch entities can be imported as solid-filled polylines. Do you want to import Hatch entities	17
Import Hatch entities	

- Use the **Browse** button to browse to the DWG or DXF file's location on the computer, select it, then click the **Open** button.
- Do not check Polylines or Boxes under the Convert lines with shared end points section at this time.
- Click **Next** or **Continue**.
- 4. On the **Select Layers** portion of the dialog:

	VISIDIE	Frozen	Convert to	
⊻ 0	×,			
DWG DOORS	×,			
DWG WALLS	~			
	~			
Select All Clear All				
		~		

- Check all of the layers that you want to import on the left
- The **Convert Selected Layer(s)** drop-down menu allows you to convert the data on any layer into a Terrain Perimeter or Elevation Data.

For more information on this topic, please visit the "Importing Terrain Elevation Data from a DXF or DWG File" resource located in the <u>Related Articles</u> section below.

- Click **Next** or **Continue**.
- 5. Under Layer Mapping:

Import Drawing Assistant		×
Layer Mapping Associate layers in the DWG/DXF drawing file with I	layers in Chief Architect.	
Map all drawing file layers to:		
CAD, Default	V Define	
 Chief Architect layers by name. 		
 Import all layer attributes into the operation of the operati	current layer set.	
O Do not import layer attributes		
You can map each layer individually and specify layer a	attributes on the Advanced Layer Mapping panel.	
Go to the Advanced Layer Mapping panel.		
	< Back Next > Cancel Hel	p

• Move the radio button to **Chief Architect layers by name**.

Note: All lines that you want to convert to walls must be located on one layer. The same is true for windows, doors, and rails. It is helpful to place like items on a single layer with unique layer attributes.

- Click **Next** or **Continue**.
- 6. Under Drawing Unit:

housing Unit		
Specify the imported drawing's original un	it of measurement and how dimension lines are importe	ed.
What unit of measurement was used to crea	ate the imported drawing?	
in	~	
Import dimension lines as:		
Import as dimensions where poss	sible.	
○ Import as cad blocks.		
DWG/DXF drawings are sometimes located f	ar from the origin (0,0).	
Move drawing to the origin		

• Select a unit of measurement from the drop-down list.

Note: Selecting the correct unit helps ensure that your imported drawing is accurately sized.

- Check the **Move drawing to the origin** box to center it in your plan.
- Click **Next** or **Continue**.
- 7. Click **Finish** or **Done** to bring the DWG or DXF drawing in to your floor plan.

After your 2D CAD drawing has been imported into Chief Architect, you may want to make some additional adjustments to their locations. For best results, delete any wall lines or polylines located between interior and exterior wall surface lines. When CAD objects are located properly, you are ready to use the CAD to Walls tool.

To use CAD to Walls

1. Select **CAD> CAD to Walls** to display the **Convert CAD to Walls** dialog.

	c	~~~~	
Wall Layer:	DWG WALLS	~	Define
Window Layer:	DWG WINDOWS \sim		Define
Door Layer:	DWG DOORS V		Define
Rail Layer:	Walls, Railings	~	Define
t Wall Types			
If set, walls with selected below t	width within 1" (25mm) of a ty will be assigned that type.	pe	
	Siding-6	~	
Wall Type 1:			

• Specify the source layers to be converted to walls, windows, doors, or rails.

It's recommended that lines representing windows and doors are not defined/associated as CAD blocks, and are on different layers.

Arcs indicating door swings help to identify a door, and as such, should be placed onto the same layer as doors.

• Specify wall types for the new walls.

To convert CAD lines to a specific wall type, the lines must be within one inch (or 25mm) of that wall type's width.

Note: If the same layer is specified as the Wall Layer and Rail Layer, all eligible walls will be converted into railings.

If the distance between the surface lines is less than the total width of the specified wall type, a copy of that wall type will be created. The width of its Main

Layer will adjust so that the overall width is equal to the specified wall's Main Layer.

- 2. Click **OK** to complete the conversion.
- 3. Create a **Camera (o)** view to see the results.
- 4. You can now further customize the walls, doors and windows created by the CAD to Walls tool, as well as specify Room Types, create cabinets and terrain, and place objects from the Library Browser.

Related Articles

- Converting Plan Files to DWG or DXF(/support/article/KB-00013/converting-plan-filesto-dwg-or-dxf.html)
- Importing Terrain Elevation Data from a DWG or DXF File(/support/article/KB-00719/importing-terrain-elevation-data-from-a-dwg-or-dxf-file.html)
- Modifying the Scale of an Imported DWG/DXF (/support/article/KB-00199/modifyingthe-scale-of-an-imported-dwg-dxf.html)
- Troubleshooting DWG/DXF File Import Issues (/support/article/KB-00283/troubleshooting-dwg-dxf-file-import-issues.html)

(https://www.instagram.com/chiefarchitect/) (https://www.houzz.com/pro/chiefarchitect/) (https://www.pinterest.com/chiefarchitect/) 208-292-3400 (tel:+1-208-292-3400) © 2000-2024 Chief Architect, Inc. Terms of Use (/company/terms.html)

Privacy Policy (/company/privacy.html)