## Restoring the Living Area Label

Reference Number: **KB-00285** Last Modified: **July 14, 2025** 

## QUESTION

The label that displays my Living Area has disappeared. How can I restore its display?

## ANSWER

If the Living Area label has disappeared or was deleted, it can be regenerated by accessing the General Plan Defaults or by performing a Plan Check.

To display the Living Area label

- 1. Select **Edit> Default Settings** 💾 from the menu.
- 2. In the **Default Settings** dialog, select **Plan** from the list, then click **Edit**.



3. In the **General Plan Defaults** dialog that displays, place a check in the **Show Living Area Label** box.

│ General Plan Defaults ×		
General	General Settings	
Angle/Grid		Warn Before Deleting Selected Objects
		Ignore Casing When Resizing Wall Openings
		Allow Editing in Select Home Designer Products
		Show Pitch as Degrees
		Use Line for Joists, Rafters, and General Framing
	Arrow Key Scroll Distanc	e: 12"
	Living Area	
	Living Area To:	Main Layer
		○ Surface
		Show Living Area Label
	Opening Indicators	
	Hinged Openings:	Opening Indicators Point to Hinge Side
	Geographic Location	
	Latitude:	48.0°   North O South
	Longitude:	117.0° 🛛 East 💿 West
	Time Zone:	(GMT - 08:00) Pacific Time (USA & Canada), Tijuan $ \smallsetminus $
Number Style.		OK Cancel Help

4. Click **OK** and **Done** to confirm the changes and close the dialogs.

If the Living Area label still does not display after enabling the setting above, try the following:

- Open not of your rooms up to specification and verify that either the **Include in Total Living Area Calculation** option or **Use Default (Included)** option is selected on the GENERAL panel. If all rooms on a floor level are set to be excluded in the total living area calculation, the Living Area label will not display.
- Select Tools> Checks> Plan Check from the menu. In the Plan Check dialog, click the Done button. When the dialog closes, check to see if the Living Area label displays.

- Next, ensure that the "Room Labels" layer is displayed in the Layer Display Options
   dialog. This is the default layer for the Living Area label. You will also want to make sure that the Text Style assigned to this layer has a Character Height value large enough to be visible in the floor plan.
- You can use one of the **Text** T tools to place a text object, then insert the Living Area (%living.area%) macro.

If you continue to have trouble with populating the Living Area label, please send a copy of the .plan file to our Technical Support department using the <u>Technical Support</u> <u>Center (https://www.chiefarchitect.com/support/article/KB-00717/using-the-technical-support-center.html)</u>.

**Related Articles** 

- Displaying Room Dimensions, Room Area, and Room Volume Using Macros (/support/article/KB-00687/displaying-room-dimensions-room-area-and-roomvolume-using-macros.html)
- Understanding How the Square Footage, or Living Area, is Calculated (/support/article/KB-00424/understanding-how-the-square-footage-or-living-area-iscalculated.html)
- Using the Technical Support Center (/support/article/KB-00717/using-the-technicalsupport-center.html)

 Image: Contrast of the service of